


1.For each Delivery pipe should be fitted with Float valve.

2.If any tank level is below ON Point Motor switches on and when water reaches full it switches off.

3. Each tank level is controller individually.

4.When one tank is full and other tank below ON point Motor switches ON, the Float valve stops over flow of Filled tank, water fills up to empty tank gets filled up to off Point.

Model : ULDX-HA-02-4T (Multi Tank Controller) .

Sri Digitek Dual pump, Dual sump with 4 Tank Controller With Level Indicator.